

Assembly Instructions for stopping plug type 377 press

Assembly Instructions
AI 284
Issue C - 02/06

BASEEFA Certificate No. BAS 04 ATEX 0168X  II 2 GD EExe II
Operating temperature range -40°C +75°C

HAWKE
International

APERTURE ACCEPTANCE DETAILS: Diameter: 20 - 20.7mm / Thickness 2 - 3mm
NOTE: No tools are required during the installation or removal of the plug.

When installed in accordance with the installation instructions, the plug will maintain an IP 66 degree of protection.

INSTALLATION

A

Ensure hole is free from debris and burrs, then push the front edge of the plug into hole from the outside of the enclosure.



B

Push the button on the plug inwards until it is flush with the rest of the plug.



REMOVAL

C

Isolate the circuits and open the enclosure lid. From inside the enclosure, push the centre of the plug until the button pops out on the other side.



D

Hold the plug at the base and remove.



Visit our Web Site at www.ehawke.com